

Priming		Painting		
1.	3 drops thinning sauce (lubricate)	1.	13 dro	ps of thinning sauce (lubricate)
2.	Add primer	2. Add paint		
	(3:1 or 4:1 primer:thinning sauce)		(2:13	paint:thinning sauce
3.	Spray		2:6	air paint:thinning sauce
	(18–20PSI dark, 35–40PSI light color)		2:8	ink:thinning sauce)
4.	Clean airbrush after each coat	3.	Spray	
	(let dry for 3 to 4 minutes)		(18-20	PSI)
5.	2 thin coats			
Varnish				
1.	3 drops thinning sauce (lubricate)			
2.	Add varnish			
3.	Spray			
	(15-20PSI)			
4.	Clean airbrush after each coat – use 1			
	to 2 drops of 99% IPA in your flow			
	(let dry, 10min to 1hr)			





Spider Webbing	Speckling		
 too much pressure or too much paint 	 too little pressure or too little paint 		
	dirty nozzle		
	 bent needle 		
Fluid Cap Bubbles	Primer Chip Off		
 Needle not fully set 	Dirty model		
 Paint dried on tip 	 Spray too far away 		